




















PAIRING YOUR HERO3 WITH THE WI-FI REMOTE

Before you can use the Wi-Fi Remote to control your HERO3 for the first time, you must pair the two devices. First, ensure both camera and remote are powered **OFF**.

On the camera:

1. Press [] to power **ON** your HERO3.
2. Press [] to turn **ON** the **Wi-Fi**, then press [] again to access the [] menu.
3. Press [] to enter the [] menu.
4. Press [] to cycle to **Wi-Fi RC**, then press [] to select it.
5. Press [] to cycle to **NEW**, then press [] to select it.
6. You will see [].

On the Wi-Fi Remote:

1. While holding down [], press and release [] once to power the remote **ON** into pairing mode.
2. When you see [] on the remote's screen, you can release [].
3. [] will appear on both screens once the devices have paired.
4. The remote will now ask if you want to **CONNECT ANOTHER?** camera.
 - a. If yes, press [] to select **YES**, then repeat the pairing process from the beginning.
 - b. If no, press [] to cycle to **NO**, then press [] to select it.

You can now use the Wi-Fi Remote to control your HERO3. For more information or help, visit gopro.com/support.